

Fold this template over the ends of your boards. Use one side of the template for the short boards and use the other side for the long boards. Drill 3/16" holes through the black dots and through your boards. It places the holes nicely and saves you some measuring!

● 4' ends ●

After drilling, assemble these boards first.

fold here



8' sides

● use these for 5/4" decking ●

● use these for 2x boards ●